

25 Series Clips Fitting Instructions



These instructions to be read in conjunction with product datasheet, available from www.gantrail.com.




Insert bolt through hole in rail supporting structure.




Place clip body over bolt.

FIGURE 4




Place cam over bolt.




 $\label{local_interpolation} \mbox{IMPORTANT}: \mbox{Ensure bolt is positioned in right-hand half of cam}.$

FIGURE 5




Using a C spanner, rotate cam clockwise to move clip body into metal-to-metal contact with bottom flange of rail.


FIGURE 6




Clip in metal-to-metal contact with bottom flange of rail.



Run nut down bolt.



Nut to make full contact with cam.



Whilst maintaining clockwise pressure with C-spanner, tighten nut to required torque given on clip datasheet.

A world of crane rail expertise.

www.gantrail.com



Gantry Railing Ltd Sudmeadow Road

Sudmeadow Road Hempsted Gloucester GL2 5HG ENGLAND

Tel: +44 (0) 1452 300688 E-mail: info@gantrail.com

